



INSTALLATION INSTRUCTION FOR CLADDING KIT: HB-16-AL-1 AND SIMILAR

WARNING: Risk of fire and electric shock!
This fixture must be installed by a qualified electrician only! **MAKE SURE ELECTRICAL CURRENT IS DISCONNECTED BEFORE KIT INSTALLATION**

DISCONNECT POWER

1. UNWRAP ALL FIXTURE COMPONENTS INCLUDING SMALL PARTS BAG ENCLOSED.

PARTS LIST:

(4) 4-40 SPACER TUBES
(4) 4-40 ALL-THREAD
(1) SPREADER
(4) 4-40 NUTS
(1) PRISMATIC ACRYLIC

2. THREAD 4-40 ALL-THREAD RODS INTO THE (4) OUTERMOST HOLES OF THE P59 PASSIVE FIXTURE'S HEATSINK.
3. SLIP SPACER TUBES OVER THE 4-40 ALL-THREAD RODS.
4. RAISE SPREADER AND ACRYLIC TO P59 PASSIVE FIXTURE AND SLIP OVER ALL-THREAD RODS. SECURE WITH 4-40 NUTS (SUPPLIED).

RECONNECT POWER