



INSTALLATION INSTRUCTIONS FOR FIXTURE: SV2 14 OR SV2 22 - SURFACE MOUNT (SV2-22 SHOWN)

WARNING: RISK OF FIRE AND ELECTRIC SHOCK! THIS FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY! MAKE SURE ELECTRICAL CURRENT IS DISCONNECTED BEFORE MAKING ELECTRICAL SPLICES.

DISCONNECT POWER

1. UNWRAP ALL FIXTURE COMPONENTS INCLUDING SMALL PARTS BAGS ENCLOSED.
2. SECURE (2) 8-32 X 3" SCREWS TO MOUNTING STRAP WITH (2) 8-32 NUTS (PROVIDED), THEN ATTACH STRAP TO JUNCTION BOX.
3. RAISE FIXTURE AFTER WIRING (IF NOT WIRING TO 0-10V DIMMING, CAP THE PURPLE AND PURPLE STRIPED LEADS), ENSURING THE MOUNTING STRAP SCREWS ARE ALIGNED WITH THE TUBES IN THE TOP OF THE FIXTURE, AND SECURE TO CEILING WITH (2) 8-32 NUTS (PROVIDED).
4. RAISE ACRYLIC OVER FIXTURE, MAKING SURE TO ALIGN SLOTS IN ACRYLIC WITH THE TABS STICKING OUT OF THE FIXTURE TO SLIP OVER, TURN AND DROP.

RECONNECT POWER

10 Strecker Road Ellisville, MO 63011 888-896-2101 888-896-2101 Fax

www.ChameleonLTG.com

info@ChameleonLTG.com Email