

## F ADAPTER PLATE - INSTALLATION INSTRUCTIONS

1. Attach thumb screw through bracket at point A and connect to holes in cladding kit.
2. Attach 8/32 X 1 ½ inch screw to bracket at point B and then to P59. Adjust screw so the P59 is flush on the bottom of the cladding kit.

